








# Atera SIGNO

Mercedes Benz  
CLA Shooting Brake (X117) 03/2015-

Mercedes Benz  
A-Klasse (W176) 09/2012-

# Atera SIGNO





Mercedes Benz  
A-Klasse (W176) 09/2012-  
CLA Shooting Brake (X117) 03/2015-  
Art. Nr. / Part-No. : 044 188  
Art. Nr. / Part-No. : 045 188



# Atera SIGNO

Mercedes Benz  
CLA Shooting Brake (X117) 03/2015-

Mercedes Benz  
A-Klasse (W176) 09/2012-



# Atera SIGNO

Mercedes Benz  
CLA Shooting Brake (X117) 03/2015-

Mercedes Benz  
A-Klasse (W176) 09/2012-

